

# Central College – No Power

Objective – computer has no power

1. Plug in the adaptor and wait a few minutes – then turn on the power
2. If no power
  - a. Remove the battery and power adapter
  - b. Press the power button to release any stored electrical energy in the computer
  - c. Reconnect the power adapter and/or battery
  - d. Press the power button

If this doesn't work, contact the ITS Help Desk at 641-628-7010 or email [itshelpdesk@central.edu](mailto:itshelpdesk@central.edu)